

## SP20 MULTITESTER

**SANWA**  
SANWA ELECTRIC  
INSTRUMENT CO., LTD.  
Denpa Bldg. Sotokanda2-Chome  
Chiyoda-Ku, Tokyo, Japan


### Instruction Manual

発売：三洋電機計器

#### [2] APPLICATION AND FEATURES

- 2-1 Application  
This instrument is portable multimeter designated for measurement of weak current circuit.
- 2-2 Features  
- Taut-band structure is adopted in the meter part.  
- A stand is equipped.

#### [3] NAME OF COMPONENT UNITS



#### [1] SAFETY PRECAUTIONS: Before use, read the following safety precautions

This instruction manual explains how to use your multimeter SP20 safely. Before use, please read this manual thoroughly. After reading it, keep it together with the product for reference to it when necessary.

The restriction given under the heading "WARNING" "CAUTION" must be followed to prevent accidental burn or electrical shock.

##### 1-1 Explanation of Warning Symbols

The meaning of the symbols used in this manual and attached to the product is as follows.

⚠ : Very important instruction for safe use.

The warning messages are intended to prevent accidents to operating personnel such as burn and electrical shock.

The caution messages are intended to prevent damage to the instrument.

⊖ : DC Voltage

⊕ : AC Voltage

Ω : Resistance

⚡ : Fuse & Dead-end protection

⚡ : Drop proof

⊕ : Ground

⊖ : Plus input

⊖ : Minus input

⚡ : Fuse

##### 1-2 Warning instruction for safe use

##### ⚠ WARNING

To ensure that the meter is used safely, be sure to observe the instruction when using the instrument.


1. Never use meter on the electric circuit that exceed 3k VA.
2. Pay special attention when measuring the voltage of AC 30Vrms (42.4 Vpeak) or DC 60V or more to avoid injury.
3. Never apply an input signals exceeding the maximum rating input value.
4. Never use meter for measuring the line connected with equipment (i.e. motor's) that generates inductive or surge voltage since it may exceed the maximum allowable voltage.

#### [4] MEASUREMENT PROCEDURE

##### 4-1 Start-up Inspection

##### ⚠ WARNING

1. Never use meter if the meter or test leads are damaged or broken.
2. Make sure that the test leads are not cut or otherwise damaged.



##### 5. Never use meter if the meter or test leads are damaged or broken.

6. Never use uncased meter.

7. Be sure to use a fuse of the specified rating or type. Never use a substitute of the fuse or never make a short circuit of the fuse.

8. Always keep your fingers behind the finger guards on the probe when making measurements.

9. Be sure to disconnect the test pins from the circuit when changing the function or range.

10. Be sure to disconnect the test pins from the circuit when changing the function or range.

11. Never use meter with wet hands or in a damp environment.

12. Never open tester case except when replacing batteries or fuse. Do not attempt any alteration of original specifications.

13. To ensure safety and maintain accuracy, calibrate and check the tester at least once a year.

14. Indoor use.

##### 1-3 Maximum Overload Protection Input

Function (Range)	Input	Maximum rating input value	Maximum overload protection input
DCV50 ~ 500			DC1000V, AC750V
ACV50 ~ 500			or PEAK MAX 1100V
DCV0.25 ~ 10		Full scale value at the ranges	* DC, AC200V
ACV10			or PEAK MAX 250V
DCA2500Ω~25kΩ	+		* DC, AC0.5A
DCA50Ω	+		* DC, AC1mA
Ω		Voltage and current input prohibited	* DC, AC200V or PEAK MAX 250V
⊖		DC2V	

Note : AC voltage is regulated by rms value of sinusoidal waves.

\* \* is within 5 second.

##### 4-2 How to Set up Range (Selection of appropriate range)

① When determining a measuring range, select a higher voltage than the value to be measured as well as where the pointer of a meter moves to a considerable extent. However, select the maximum range and measure in case the extent of value measured cannot be predicted.

② Appropriate range for measuring a resistance (Ω) Select the range that the pointer indicates approximately in the center.

##### 4-3 Preparation for Measurement

Turn the zero position adjuster so that the pointer may align left to zero position. Select a range proper for the item to be measured and set the range selector accordingly.

##### 4-4 Voltage Measurement

##### ⚠ WARNING


1. Never apply an input signals exceeding the maximum rating input value.
2. Be sure to disconnect the test pins from the circuit when changing the function.
3. Select the maximum range and measure in case the extent of value to be measured can not be predicted.
4. Always keep your fingers behind the finger guards on the probe when making measurements.

##### 4-4-1 DCV Measurement (⊖) Maximum rating input value 500VDC


###### 1) Applications

Measures batteries and d.c. circuits

2) Measuring ranges  
0.25/2.5/5/10/50/100 (6 ranges)




- 4-4-2 ACV Measurement (—) Maximum rating input value 50V AC.
- Connect the test lead of the black plug to the - input terminal and the red plug to the + input terminal.
  - Set the range selector knob to an appropriate ACV range.
  - Apply the red and black test pins to measured circuit.
  - Read the value of the pointer by V. A scale.
  - After measurement, remove the red and black test pins from the circuit measured.
  - Since this instrument adopts the mean value system for its AC voltage measurement circuit, AC waveform other than sine wave may cause error.
  - Errors occur under such frequencies other than specified specification.



4-5 DCA Measurement (—) Maximum rating input value 0.25A DC

1. Never apply voltage to the input terminals.  
2. Be sure to make a series connection via load (Please see to above drawing!)  
3. Do not apply an input exceeding the maximum rated current to the input terminals.




- Is the appearance not damaged by falling?
  - Test leads and fuse
  - Is the cord of the test leads not damaged?
  - Is the core wire not exposed at any place of the test leads?
- If your instrument fails in any of the above items, do not use it and have it repaired or replace it with a new one.
- Make sure that the test leads are not cut.
  - Calibration
- The calibration and inspection may be conducted by the dealer, or more information, please contact the dealer.
- 3 How to Replace Battery and Fuse


1. If the rear case or the battery lid is removed with input applied to the input terminals, you may get electrical shock. Before starting the work, always make sure that no inputs is applied.
2. Be sure to use the fuse is same rating so as to ensure safety and performance of tester.
3. When operator remove the battery lid, do not touch the internal parts or wire with hand.

How to replace the battery

- Remove the battery lid screw with a screwdriver.
- Remove the battery lid.
- Take out the battery and replace it with a new one.
- Attach the battery lid and fix it with the screw.



- Connect the testlead of the black plug to the - input terminal and the red plug to the + input terminal.
- Set the range selector knob to an appropriate DCA range.
- Apply the black test pin to the negative potential side of the circuit to measure and the red test pin to the positive potential side.
- Read the value of the pointer by V. A scale.
- After measurement, remove the red and black test pins from the circuit measured.




4-6 Resistance Measurement (Ω)

- Never apply voltage to the input terminals.

- Connect the testlead of the black plug to the - input terminal and the red plug to the + input terminal.
  - Set the range selector knob to an appropriate Ω range.
  - Short the red and black test pins and turn the Ω adjuster so that the pointer may align exactly to 0 Ω.
  - Apply the black and red test pin to the measured resistance.
  - Read the value of the pointer by Ω scale.
  - After measurement, remove the red and black test pins from the resistor measured.
- Note : Be sure to use the same rated fuse. In case a fuse other than the same rated one (See "SPECIFIC CAUTIONS") is used, error in indication occurs and/or circuit protection is made unable.

- Caution : If the pointer falls to swing up to 0 Ω even when the Ω adjuster is turned clockwise fully, replace the internal battery with a fresh one.



4-7 Battery check

- Never apply an input signals exceeding the battery voltage to the input terminals.

- Connect the testlead of the black plug to the - input terminal and the red plug to the + input terminal.
- Set the range selector knob to an appropriate Ω or Ω range.
- Apply the black test pin to the negative potential side of the circuit to measure and the red test pin to the positive potential side.
- Read the value of the pointer by Ω scale.

4-8 Measuring Capacity (μF)

1. Never apply voltage to the input terminals.  
2. Do not measure as for a condenser of a charged condition.

- Connect the testlead of the black plug to the - input terminal and the red plug to the + input terminal.
- Set the range selector knob to an appropriate μF × 1 range.
- Short the red and black test pins and turn the Ω adjuster so that the pointer may align exactly to 0 Ω.
- Apply the black and red test pin to the measured capacitor.
- Read the value of the pointer by μF scale.

enough cushioning material stuffed around it.

- 6-2 For information or enquiries  
If you need information regarding purchase of repair parts or if you have any other sales related questions, please contact the dealer, selling agent, or maker.

[7] SPECIFICATIONS

7-1 General Specifications

- AC Rectifier Form : Half-wave rectifier form  
Meter type : Internal reagent type, Taut band meter  
Accuracy Assurance Temperature/Humidity Range : 21 ~ 25°C, 75%RH max. No condensation  
Operating Temperature/Humidity Range : 3 ~ 43°C, 80%RH max. No condensation  
Storage temperature/Humidity Range : -10 ~ 50°C, 70%RH max. No condensation  
Internal Battery : R6 (IEC) or UM-3 1.5V × 2  
Internal fuse : φ6.3 × 30mm 0.5A/250V Fast fuse  
Blowout capacity 500A
- Dimension and Weight  
: 144(H) × 99(W) × 41(D)mm - approx 270g  
Accessories : Instruction manual 1 Spare fuse 1 Test leads (TL-61) 1

7-2 Optional Accessories

- Clip adapter CL-11 (Red, Black 1set)
- HV probe HV-
- Carrying case C-SP
- Carrying Case C-SPH
- Alligator Clip CL-5
- IC Test Clip CL-5IC

4-9 DC High Voltage measurement (Optional HV Probe)

- The probe is designed for the measurement of very small direct current circuit. Never use the probe to measure high voltage in power lines, such as transmission and distribution lines. It is very dangerous.

- Connect the HV Probe of the black plug to the - input terminal and the red plug to the + input terminal.
- Set the range selector knob to [HV PROBE] range.
- First, connect the clip (black) of the probe to the earth line (-) in the circuit to be measured, and then apply the measuring pin on the probe body to your measuring point.
- Read the value of the pointer by V. A scale, measured value in terms of kV.

4-10 Optional Temperature Probe (T-1HP) Max value +200°C

- Connect the pin of the temperature probe to the + input terminal and the black plug to the - terminal.
- Set the range selector to ΩC PROBE range.
- Adjust the pointer to the 0 Ω by the range selector. Remove the pin of the temperature probe from the + terminal and then connect the red plug.
- Connect the measuring pin to a point to be measured. Read the value on ΩC scale when the pointer is stabilize.

4-11 End of Measurement

Turn off the range to prevent voltage applied to resistance and current ranges.

[5] MAINTENANCE

1. This section is very important for safety. Read and understand the following instruction fully and maintain your instrument properly.  
2. The instrument must be calibrated and inspected at least once a year to maintain the safety and accuracy.

5-1 Maintenance and Inspection

7-3 Measurement Range and Accuracy

- Accuracy assurance range : 23°C ± 2°C, 45 ~ 75%RH max  
No condensation  
Horizontal (± 5°)  
ACV accuracy in the case of same wave AC.

Function	Full scale value	Accuracy	Remarks
DCV (—)	0.25/2.5/15/50/100 500	± 3% against full scale	Input impedance 20kΩ/V
ACV (—)	10/50/250/500	± 3% against full scale	Input impedance 9kΩ/V
DCA (—)	50 μA/2.5mA/25mA/0.25	± 3% against full scale	Input impedance 2kΩ/V
Ω	20/200/2000/20k	± 3% of air	Max. Value 2kΩ Release voltage 3V
Battery Check	2.0V	—	Load resistance 20Ω
Capacity (μF)	500	—	Peak indication of the maximum value by digital output in the cartridge
HV	DC25kV	± 2% with probe	Optional HV-10
Temp. °C	-20 ~ +200	± 3% against full scale	Optional THP

Specifications and external appearance of the product described above may be revised for modification without prior notice.